

# Моудль активации пожаротушения

**ВА-40**

## Технические характеристики

Архангельск (8182)63-90-72  
Астана +7(7172)727-132  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04


Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81  
Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93



### Features

- Adjustable to all conventional and analogue addressable fire alarm systems
- Simple mounting in centrals or conduit boxes
- Prepared for mounting on standard TS rails
- Meets the EMC demands in relation to CE-labelling
- Monitored inputs and outputs
- Constructed for duplex 24V DC power
- All connections on pluggable switches
- Easily connected to extern control panel



### Applications

BA-40 is an extinguishing release module used in automatic fire extinguishing system.

The module consists of 2 extinguishing zones. Each zone utilizes common functions and controls and monitors an extinguishing zone (an area, a room, a machine, an electrical cabinet etc.). Every zone has 5 inputs, 4 outputs and 7 LED indicators. The common functions consist of 4 inputs, 4 outputs and 3 LED indicators.

Several BA-40s can be used if more than two extinguishing zones are required.

The delay period before release of the extinguishant is determined by the switch settings on block S1, switch S1.1 and S1.2. It is also possible to invert common fault signal (39) and turn off the short circuit monitoring of the signal inputs.

#### Inputs:

- Automatic release input control 1 and 2, monitored for breaks and short circuits. An active signal on input 1 or 2 starts the delay period. Activation of the 2<sup>nd</sup> input control during the delay period will activate the extinguishing output at the end of the delay time.
- *Manual release input.* Monitored for breaks and short circuits. Two-stage function input. S1 gives alarm at common sounder alarm output and first alarm output. S2 gives manual release.
- Break- and short circuit monitored
- Blocking of automatic release function. Break- and short circuit monitored. Activation of the input during delay period inhibits automatic release in the actual zone. The input is also used for termination of the delay period.
- Pressure monitoring. Monitored for breaks and short-circuit. Open contacts indicate too low pressure in extinguisher.

#### Outputs:

- Alarm output 24V DC / 0,5A. Activated at first alarm and open cover on manual release box. Cancelled by active signal on input for silencing alarm. Polarity dependent alarm sounders.
- Output for indication of active signal on one of the automatic release input controls. Transistor-output, 100mA, non-monitored.
- Indication of extinguishing equipment released. Non-monitored. Max. 24V DC / 1A
- Common fault output. Transistor output, 100mA, non-monitored

### Light indicators (LED):

#### Status indications:

- Red indicator illuminates when the 1<sup>st</sup> automatic release input is activated. The delay period starts.
- Red indicator illuminates when the extinguishant is released.
- Yellow indicator illuminates when automatic release is inhibited (manual only)

#### Fault indications:

- Yellow indicator illuminates when there is a fault condition on one of the automatic control inputs (e.g. break / short circuit).
- Yellow indicator illuminates when there is a fault condition on the output release circuit (e.g. break / short circuit).
- Yellow indicator illuminates when there is a fault condition on the manual release input, automatic inhibit circuit or the pressure monitoring circuit (e.g. break / short circuit).
- Yellow indicator illuminates when the pressure in the extinguishant tank is too low.

### Common functions

#### Inputs:

- 27V DC / 3,15A, Power inputs 1 and 2. Monitored (>18V, <31V DC).
- Closing contacts silences the sounder alarm outputs (sounders, sirenes). The input is non-monitored.
- Input for reset of control module. Short-circuit > 5-10 seconds gives steady light in fault power supply LED and activates fault output
- Connection of BAV-45

#### Outputs

- Sounder alarm output 24V DC / 0,5A. Activated at first alarm and open cover on manual release box. Cancelled by active signal on input for silencing alarm. Polarity dependent alarm sounders.
- Output for indication of active signal on one of the automatic release input controls. Potential free relay.
- Common fault output. Transistor output, 100mA, non-monitored.
- 24V DC output for external equipment. Monitored, 0,5A fuse.

## Technical specifications

Dimensions	HxBxD = 230x126x65 mm
Weight	0,6 kg
Material	Plasthus m/ståldeksel
Protection degree	IP30
Power supply 1 and 2	2 stk. 24 V DC inputs / 3A
Power consumption (normal)	
1 zone	70 mA
2 zones	80 mA
Power consumption (alarm)	
1 zone	1,5A
2 zones	3A
Cable dimension	2 x 1,5mm <sup>2</sup>
Release circuits	22-24V DC / 1A
Manual release circuit	BW-20A

## Light indicators (LED):

- Green indicator is lit during normal operation (when one of the power inputs is connected to 24V DC).
- Yellow indicator illuminates with following fault conditions: Communication fault between BA-40 and operator panel BAV-45 if this panel is mounted, short circuit on reset input or hold on reset button for more than 5-10 seconds, the fuse for the 24V power output (F3=0,5A) is defect or 27V DC is missing on one of the power inputs (Power 1 or Power 2).
- Yellow indicator illuminates when there is a fault condition on the sounder alarm output (e.g. break / short-circuit).

## DIP-switch


The DIP switch is mounted on the circuit board on the left top. Be aware that the switch is shown the way it looks when the BA-40 unit is in an upright position. The status (normal / reversed) on the common fault signal (output 39) is determined by the switch settings on switch S1.3 (as shown on the drawing). The delay period before release of the extinguishant is determined by the switch settings on block S1, switch S1.1 and S1.2. Short circuit monitoring of input signals is determined by switch S1.4.

Delay period for release of extinguisher after activation of one of the control inputs. Settings on S1.1 and S1.2. (Factory settings: 60 seconds)			
OFF ON	OFF ON	OFF ON	OFF ON
1 — 2 —	1 — 2 —	1 — 2 —	1 — 2 —
3 — 4 —	3 — 4 —	3 — 4 —	3 — 4 —
0 seconds	30 seconds	60 seconds	180 seconds

Status common fault signal (output 39) / Settings on S1.3. (Factory settings: Normal)	
S1.3. —	S1.3. —
Normal Gives 0-volt control at failure.	Reverted Breaks 0-volt control at failure.

Status for monitoring signal input/ Settings S1.4 (Factory settings: OFF)	
S1.4. —	S1.4. —
Break and short circuit monitored.	Break monitored only.

S1.1	1st. Alarm	1st. Alarm	Zone 1
S1.2	Gas released	Aut. Inhibited	
	Release outp.		
	Press. contr.		
	Contr. inputs		
	Man./Aut./Press		
1 0V	Input control 1	Zone 1	
2 Signal			
3 0V	Input control 2		
4 Signal			
5 —	Manual release.		
6 +	Input		
7 —	Automatic inhibit.		
8 +	Input		
9 —	Pressure monitoring.		
10 +	Input		
11 0V	Input control 1	Zone 2	
12 Signal			
13 0V	Input control 2		
14 Signal			
15 —	Manual release.		
16 +	Input		
17 —	Automatic inhibit.		
18 +	Input		
19 —	Pressure monitoring.		
20 +	Input		
21 — 24V DC	Power 1		
22 +			
23 — 24V DC	Power 2		
24 +			
	Silence Sounders.	Zone 1	
	Sounders. Input		
	+ 35		
	- 36		
	+ 37		
	- 38		
	Com. fault output		
	39		
	NO 40		
	Common 1st. Alarm C		
	41		
	NC 42		
	Sounder output 24VDC		
	- 43		
	24V DC 0,5A utg.		
	- 44		
	+ 45		
	Zone 1 + 47		
	Release 24VDC/1A - 48		
	Zone 2 + 49		
	Release 24VDC/1A - 50		



**По вопросам продаж и поддержки обращайтесь:**

Архангельск (8182)63-90-72  
Астана +7(7172)727-132  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04

Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81  
Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93

**Единый адрес для всех регионов: [acn@nt-rt.ru](mailto:acn@nt-rt.ru) || [www.autronica.nt-rt.ru](http://www.autronica.nt-rt.ru)**