

Мультисистема тревоги

AU 2.1

Технические характеристики

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04

Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93



Multi Alarm System Type AU 2.1

For various applications

Product datasheet



AU 2.1 is a multipurpose PCB for alarm handling. It is suitable for any type of sensor with output 4-20ma or 0-10V. Measuring range and alarm levels can be programmed to different applications.

AU 2.1 can be configured to give max. 4 alarms. alarms can be triggered by analog value or by digital input, or a combination. If it is configured with i.e. two analogue alarm levels (A and B), it has two digital alarm inputs available (C and D). If the PCB is configured with 4 analogue alarm levels, the last alarm (D) will only be detected if a voting condition is present.

An alarm is indicated by sounding buzzer, flashing alarm LED and light in alarm buttons. The alarm relay driver outputs can be monitored for overload and line breakage.

The system fulfils the latest IMO and classification societies' rules and regulations.

EXAMPLE ON SYSTEMS THAT WE SUPPLY ONBOARD SHIPS

**GAS ALARM SYSTEM – TYPE OGS 2.1**

For Eex area and accommodation on all types of tankers

Standard features


- Combustible/IR type hydrocarbon sensor
- Electrochemical Oxygen sensor
- Electrochemical Hydrogen Sulphide sensor
- Power failure relay output
- Common gas alarm relay output (for each gas type)
- Common system alarm failure relay output
- Bridge remote panel

**PRESSURE ALARM SYSTEM – TYPE OPS 2.1**

For cargo tank Eex area and other applications

Standard features

- SS 316 pressure sensor(s) with deck box
- SS 316 Shut-off valves and brackets
- Power failure relay output
- Common alarm relay output (for each tank)
- Common system alarm failure relay output
- Bridge remote panel.

**TEMPERATURE ALARM SYSTEM – TYPE OTS 2.1**

For eex area and other applications

Standard features

- Various PT 100 elements with selectable range
- Transmitter including junction box
- Power failure relay output
- Common temp. alarm relay output (each point)
- Common system alarm failure relay output
- Bridge remote panel.

AUTRONICA FIRE AND SECURITY AS

Head office, NO-7483 Trondheim, Norway Tel: +47 73 58 25 00, fax: +47 73 58 25 01, e-mail: info@autronicafire.no

Oil and Gas division, Stavanger, Norway Tel: +47 51 84 09 00, fax: +47 51 84 09 99

Maritime division, Spikkestad, Norway Tel: +47 31 29 55 00, fax: +47 31 29 55 01

Tønsberg, Norway Tel: +47 33 38 25 00, fax: +47 33 38 25 25

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04

Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: acn@nt-rt.ru || www.autronica.nt-rt.ru