

# AUTRONICA

## Проводка AutoSense

### Краткое описание

Архангельск (8182)63-90-72  
Астана +7(7172)727-132  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04

Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81  
Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93



## Piping - AutoSense series

---

**Straight pipe L=3M HFBS 16**

Straight pipe L=3M HFBS 16

---

**Straight pipe L=3M HFBS 25**

Straight pipe L=3M HFBS 25

---

**Normal bend 90DEG HFNB 16**

Normal bend 90DEG HFNB 16

---

**Normal bend 90DEG HFNB 25**

Normal bend 90DEG HFNB 25

---

**Connector HFSM 16**

Connector HFSM 16

---

**Connector HFSM 25**

Connector HFSM 25

---

**Gland for cabinet HFAFT/MSB 16**

Gland for cabinet HFAFT/MSB 16

---

**Gland for cabinet HFAFT/MBS 25**

Gland for cabinet HFAFT/MBS 25

---

**T-piece for capillary tube CM10917**

T-piece for capillary tube CM10917

---

**Suction point for capillary tube, false ceiling CM10919**

Suction point for capillary tube, false ceiling CM10919

---

**Suction point for capillary tube, cabinet M10913**

Suction point for capillary tube, cabinet M10913

---

**Blind plug DPD16-01**

Blind plug DPD16-01

---

**Blind plug DPD-25-01**

Blind plug DPD-25-01

---

**Pipe fastener HFCL 16**  
Pipe fastener HFCL 16

---

**Pipe fastener HFCL 25**  
Pipe fastener HFCL 25

---

**Saddle HFSBS 16**  
Saddle HFSBS 16

---

**Saddle HFSBS 25**  
Saddle HFSBS 25

---

**Box 165x105x64 HPKGH 100 OP**  
Box 165x105x64 HPKGH 100 OP

---

**Padding HVKS 310**  
Padding HVKS 310

---

**Capillary tube, 10mm diametre**  
Capillary tube, 10mm diametre

---

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72  
Астана +7(7172)727-132  
Белгород (4722)40-23-64  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89  
Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04

Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Липецк (4742)52-20-81  
Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Новосибирск (383)227-86-73  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Пермь (342)205-81-47  
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Тверь (4822)63-31-35  
Томск (3822)98-41-53  
Тула (4872)74-02-29  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Уфа (347)229-48-12  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Ярославль (4852)69-52-93

Единый адрес для всех регионов: [acn@nt-rt.ru](mailto:acn@nt-rt.ru) || [www.autronica.nt-rt.ru](http://www.autronica.nt-rt.ru)