

AUTRONICA

Панели управления для систем подавления огня

Краткое описание

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04

Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93



Control panels

BA-45 is a control and extinguishing panel used together with automatic fire alarm and extinguishing systems.

The panel consists of an operator panel plus the integrated Extinguishing Release Module BA-40.



Control/Monitoring unit with operator panel BA-45/102

Extinguishing control panel and extinguishing release module (ERM) BA-40 mounted in a UEA-323/1 cabinet (designed for the AutoSafe interactive fire-alarm system). Dimensions: HxWxD = 350x350x190 mm.



Control/Monitoring unit with operator panel BA-45/302

Extinguishing control panel and extinguishing release module (ERM) BA-40 mounted in a UEA- 314 cabinet (designed for the BX-10 fire-alarm panel). Dimensions: HxWxD= 195x350x128 mm.



Control/Monitoring unit with operator panel BA-45/402

Extinguishing control panel and extinguishing release module (ERM) BA-40 mounted in a UEA-322 cabinet (designed for the BX-10 Fire-alarm panel). Dimensions: HxWxD = 350x350x128mm.



Control/Monitoring unit with operator panel BA-45/502

Extinguishing control panel mounted on a standard 19" mounting plate, and the extinguishing release module (ERM) BA-40 connected by a 1 metre long ribbon cable. Dimensions: HxWxD = 266x483x55mm.



Control/Monitoring unit with operator panel BA-45/602

Extinguishing control panel mounted on a mounting plate, adapted to the following cabinets: UEA-22/1, -22/2, -23/1 and -23/2. The extinguishing release module (ERM) BA-40 is connected to the panel by a 50 cm long ribbon cable. Dimensions: HxWxD=309x445x



Operator panel BAV-45

Extinguishing control panel, for use with the extinguishing release module (ERM) BA-40. Dimensions: HxWxD=195x350x53 mm.

Cabinet BU-250/3

Cabinet for extinguishing system

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04

Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15

Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: acn@nt-rt.ru || www.autronica.nt-rt.ru